



Emergency Backup Power Supply Replacement Instructions

For System: **GE Allegro**

- 1) Call **1 800 653-9111** to have your system placed on test.
- 2) Confirm you received the correct backup power supply from ADT. (Picture 1)
- 3) Open the front cover of the main control keypad by lifting the tab located on the top and pulling back. (Picture 2)
- 4) Unplug the leads from the old emergency backup power supply. (Picture 3)
- 5) Remove old emergency backup power supply and replace with new emergency backup power supply.
- 6) Plug in new emergency backup power supply.
- 7) Close the cover of the control panel.
- 8) Take your old emergency backup power supply to the nearest recycling centre.
- 9) Test system after replacing battery.



4.8V Rechargeable Battery



(Picture 1)

Lift up tab to open keypad panel



(Picture 2)

Unplug power leads

Backup Power Supply



(Picture 3)