



# Emergency Back-up Power Supply Replacement Instructions

## For System: GE Simon 1 & 2 System


- 1) Call **1 800 653-9111** to have your system placed on test.
- 2) Confirm you received the correct backup power supply from ADT. (Picture 1)
- 3) Press the plastic tab located on top of the unit down and open the front cover of the system keypad. (Picture 2)
- 4) Unplug the old emergency backup power supply.
- 5) Remove old emergency backup power supply and replace with new emergency backup power supply.
- 6) Punch in 4-digit code on the red numbered keys.
- 7) Press the test button until you hear sensor test.
- 8) Press the "DONE" button.
- 9) Close the system keypad cover.
- 10) Take your old emergency backup power supply to the nearest recycling centre.
- 11) Test system after replacing battery.



Emergency Backup Power Supply

(Picture 1)

Press down plastic Tab and open up panel



Emergency Backup Power Supply

(Picture 2)