



Emergency Backup Power Supply Replacement Instructions

For the GE Simon XTi system


- 1) Call **1 800 653-9111** to have your system placed on test.
- 2) Confirm you received the correct backup power supply from ADT. (Picture 1)
- 3) Remove front trim plate (use coin or flat screwdriver). (Picture 2)
- 4) Once the front trim plate has been removed, remove the 2 screws located at the top of the panel. Once the screws are removed, lift the left and right tabs up with a small flathead screwdriver and swing chassis down. (Picture 3)
- 5) Using 2 fingers, press clip on battery terminal and pull leads out. (Picture 4)
- 6) Remove old emergency backup power supply and replace with new emergency backup power supply. (Picture 5)
- 7) Close chassis, re-install 2 screws, and replace front trim plate.
- 8) Test system after replacing battery.
- 9) Call the monitoring station, confirm signals, and remove test.



Take your old emergency backup power supply to the nearest recycling centre.



(Picture 1)



(Picture 2)



(Picture 3)



(Picture 4)



(Picture 5)