



Emergency Back-up Power Supply Replacement Instructions

For System: First Alert Ready Guard & Ademco Lynx

- 1) Call **1 800 653-9111** to have your system placed on test.
- 2) Confirm you received the correct backup power supply from ADT. (Picture 1)
- 3) Press the 2 tabs located on the top of the panel, then swing cover down. (Picture 2)
- 4) Remove the set screw holding the emergency back-up power supply drawer in place. (Picture 3)
- 5) Remove old emergency backup power supply drawer and replace with new emergency backup power supply.
- 6) Replace the set screw to hold the drawer in place.
- 7) Close the front cover.
- 8) Take your old emergency backup power supply to the nearest recycling centre.
- 9) Test system after replacing battery.



OR



(Picture 1)

Push 2 tabs to open keypad panel



(Picture 2)



Remove set screw to replace power supply drawer.

(Picture 3)